



# HOW TO MEASURE THE ENERGY USED TO FIRE CLAY BRICKS

A PRACTICAL GUIDE FOR BRICKMAKERS, FIELD-WORKERS AND RESEARCHERS

## Introduction

In 1996 ITDG (now known as Practical Action) undertook a project working with small-scale brickmakers in Peru, Ecuador and Zimbabwe. The idea is to disseminate appropriate, energy efficient principles and practices. But what is an energy efficient brick firing technology? How do you measure it? And how do you compare it with technologies used in other places?

Data on energy use in brickmaking has generally been collected and presented in a random fashion. It's often of very little use when trying to evaluate and compare processes. For example, a report may state 'brickmakers use four sacks of coal to fire a thousand bricks.' Fine, but what does this tell us about the energy used? We don't know the mass of a sack of coal. We don't know its calorific value. And we don't know anything about the bricks. What type of soil are they made from, and how much heat is needed for vitrification - the formation of the ceramic bond? How wet were they going to the kiln - how much fuel was used simply to dry them? What is their mass? (Bigger, heavier bricks obviously take more energy to fire.) And how well burned are they? In short, we know next to nothing useful.



Figure 1: Brickmaker lighting a kiln with a liquid fuel burner. Photo:

This technical brief details a way of gathering and presenting information on brick firing. If the method is followed, it will allow not only the energy use of a particular kiln to be calculated, but also the efficiency to be compared to others world-wide. There are difficulties involved in establishing a methodology. For example, some

scientific knowledge is implicit. Also, facilities around the world and the resources available to those monitoring brick firing will be different. As far as possible, the method presented here minimises costs and the need for specialist services.



Figure 2: Firing bricks using wood as a fuel. Photo: Practical Action.

Practical Action, The Schumacher Centre, Bourton on Dunsmore, Rugby, Warwickshire, CV23 9QZ, UK  
T +44 (0)1926 634400 | F +44 (0)1926 634401 | E [infoserv@practicalaction.org.uk](mailto:infoserv@practicalaction.org.uk) | W [www.practicalaction.org](http://www.practicalaction.org)

Practical Action is a registered charity and company limited by guarantee.  
Company Reg. No. 871954, England | Reg. Charity No.247257 | VAT No. 880 9924 76 |  
Patron HRH The Prince of Wales, KG, KT, GCB

## Background

The factors which affect energy use in brickmaking are:

- The nature of the clay: refractoriness - resistance to change by heat; the presence of fluxes - substances which aid vitrification; intrinsic calorific value.
- The moisture content of 'green' bricks going into the kiln.
- The type of fuel used, its calorific value, moisture content, and distribution.
- The design of kiln.
- The skill of the brickmakers controlling the burning process
- The climatic conditions: ambient temperature, wind direction and strength...

Normally, it's the effect of kiln design which is being investigated. Either that or varying the operating conditions of similar kilns. Here, the way we gather data takes account of the nature of the clay and its effect on energy consumption. We also consider only the energy used in firing, ruling out drying energy, so we can compare processes directly. Then we propose a way of measuring how much *heat-work* has actually been done - this is so we can take account of how well bricks are fired. (It would be easy to think a process was efficient because it used very little energy and then find the bricks were only dried mud - not vitrified at all!)

## Data collection

We categorise clay as *high temperature* (vitrifying above 1,000°C), *medium temperature* (vitrifying between 950 and 1,000°C), or *low temperature* (vitrifying below 950°C). This means access to a laboratory kiln which can reach such temperatures. The procedure is to mould cones approximately 70 mm high with a base diameter around 15 mm. Cones are placed in the kiln leaning slightly so that when vitrification temperature is reached the top bends over. This temperature is noted and the clay categorised accordingly.

The exact number of bricks being fired is needed. This is easier to determine if bricks are stacked in thousands prior to firing. Alternatively, the bricks in each layer can be counted as the kiln is built. Then we need to know the mass of the bricks. A convenient number of green bricks (perhaps 1 per 1,000, but not less than 24) should be selected at random and weighed. Thence an average 'wet mass' can be calculated. Now we need to know the moisture content of the green bricks to calculate the energy needed simply to dry them. The selected bricks can be dried in a conventional oven or a simple field oven. The important thing is to keep bricks between 80 and 100°C and weigh them periodically until no further weight loss is noted. The average 'dry mass' can then be found. With this data it's possible to calculate the mass of water and the drying energy:

$$\text{Moisture content (wet basis)} = \frac{\text{wet mass} - \text{dry mass}}{\text{wet mass}}$$

$$\text{Mass of green bricks} = \text{avg. mass of green brick} \times \text{no. of bricks}$$

$$\text{Total moisture content} = \text{moisture content of brick} \times \text{mass of bricks}$$

$$\text{Drying energy} = \text{specific drying energy} \times \text{total moisture content}$$

(Where specific drying energy' = 2,591 kJ/kg of moisture)

All fuel used should be weighed. If a fuel such as sawdust or pulverised fly ash is mixed into the body of bricks, its mass must also be determined. A sample of each fuel used should be taken promptly to test for calorific value and moisture content. If the clay has a natural fuel content, it too should be sent for testing.

If such test facilities are unavailable or unaffordable, then the best that can be done is to use the most recent local data. If a value is found in this way, it should *not* be recorded as the

specific calorific value and a note should be made of the source of the information. From this data the total energy used is calculated:

$$\text{Total energy} = \text{mass of fuel} \times \text{net calorific value}$$

And the firing energy is obtained by subtracting the energy used for drying

$$\text{Firing energy} = \text{total energy} - \text{drying energy}$$

We need to know how well bricks are fired, or rather the *heat-work* done. Testing brick properties such as compressive strength will not give useful data to compare kilns because properties are affected by factors other than firing. The effectiveness of a firing process is a function of time and temperature, but the relationship is not linear. Bricks fired at 1,000°C for 10 hours would not be the same as bricks fired at 100°C for 100 hours! We could plot temperature against time for various points in the kiln and present this graphically to qualify energy use. However, thermometry to measure such high temperatures is expensive<sup>1</sup>.

A more affordable alternative is to use Buller's Bars<sup>2</sup> placed strategically in the kiln. Buller's Bars are about 57 mm long and are made from ceramic material which melts at set temperatures. They come in a range from 590 to 1,525°C. Four bars which melt at different temperatures can be placed on a refractory stand to form a 'thermoscope'. Thermoscopes are placed as required in the kiln.

Once the kiln is fired and cooled, a representative sample of bricks - the same number as before - should be weighed, and the average fired mass calculated. Now we can calculate the total mass of fired brick and the specific firing energy:

$$\text{Mass of fired brick} = \text{mass of a fired brick} \times \text{number of fired bricks}$$

$$\text{Specific firing energy} = \frac{\text{Firing energy}}{\text{Mass of fired brick}}$$

## Presenting results

Ultimately, the results of a brick firing process would consist of:

- The specific energy used.
- The moulding process.
- The clay vitrification temperature categorisation.
- The Buller's Bar numbers for different locations, and/or an average number.
- A statement of qualifying information, comments and observations

*This brief contains a photocopiable monitoring form for recording data and calculations. There is also an example of a completed form for guidance, and a checklist to ensure all the vital data has been recorded.*

<sup>1</sup>At 1998 prices, thermometry to monitor a 20,000 brick kiln would cost approximately £1,500 (obviously this hardware should be re-usable). Using Buller's Bars would cost about £70 per kiln.

<sup>2</sup> Buller's Bars can be obtained from Taylor Tunnicliff Ltd., Normacot Road, Longton, Stoke-on-Trent, ST3 1PA, UK; tel. 44 (0)1782 501174; fax. 44 (0)1782 328807.

## Checklist

The following is a list of information which must be noted:

- (1) *Name of brickmaker, location and/or address of brickworks*  
☐
- (2) *Clay type in terms of its vitrification temperature*  
☐
- (3) *Moulding process*  
☐
- (4) *Type of kiln*  
☐
- (5) *Start and finish dates and times (duration of firing)*  
☐
- (6) *Weather conditions*  
☐
- (7) *Exact number of green bricks going into the kiln*  
☐
- (8) *Mass of green bricks*  
☐
- (9) *Mass of dry bricks*  
☐
- (10) *Mass of fuel(s) used in the kiln*  
☐
- (11) *Calorific value of the fuel(s)*  
☐
- (12) *Heat-work done (Buller's Bar numbers)*  
☐
- (13) *Mass of fired bricks*  
☐

# technical brief

**MONITORING FORM: Energy consumption of brick firing processes**

<b>Name of producer</b> Fambidzanai Training Centre (FTC)	<b>Location/address</b> 4 Dovedale Rd, Stapleford, Mount Hampden, Harare.	<b>Dates and times of firing</b> <b>Start</b> 1 Jan. 1998 <b>Finish</b> 15 Jan. 1998
<b>Type of clamp/kiln</b> Layered, scoved clamp	<b>Type of fuel</b> Boiler waste	<b>Mass of fuel used (kg)</b> 4,680
<b>Calorific value (kJ/kg)</b> <b>Gross</b> 20,170 <b>Net</b> 19,180 <b>Moisture content (%) ?</b>	<b>No. of green bricks in kiln</b> 14,817	<b>Mass per brick (kg)</b> <b>green</b> 3.65 <b>dry</b> 3.25 <b>fired</b> 3.10
<b>Brick moisture content (%)</b> = $(3.65 - 3.25) \times 100/3.65$ = 10.96 (wet basis)	<b>Method of forming</b> Semi-dry pressing (Ceratec press machine)	<b>Weather conditions</b> Intermittent heavy rain, but clamp sheltered by roof
<b>Calculation of kiln efficiency</b> <b>Mass of green brick (kg)</b> $14,817 \times 3.65 = 54,082$ <b>Mass of dry brick (kg)</b> $14,817 \times 3.25 = 48,155$ <b>Total moisture content (kg)</b> $14,817 \times (3.65 - 3.25) = 5,927$ <b>Drying energy (kJ)</b> $2,591 \times 5,927 = 15,356,857$ <b>Total energy (kJ)</b> $4,680 \times 19,180 = 89,762,400$ <b>Firing energy (kJ)</b> $89,762,400 - 15,356,857 = 74,405,543$ <b>Mass of fired brick (kg)</b> $3.10 \times 14,817 = 45,933$ <b>Specific firing energy (kJ/kg)</b> $74,405,543/45,933 = 1,620$		<b>Qualifying information:</b> <b>(i) Soil vitrification category</b> High temperature ( $>1000^{\circ}\text{C}$ )  <b>(ii) Bullers Bar no.</b> = 13 ( $\approx 890^{\circ}\text{C}$ )‡ <u>And/or</u> <b>(iii) Avg. firing temp. (<math>^{\circ}\text{C}</math>) ?</b> <b>(iv) Firing time (hrs) ?</b>
<p><b>Notes:</b> ‡Thermoscopes contained bars 11, 13, 15 &amp; 17. Only six of eighteen were recovered. Three from the sides of layers 4 and 15 and the centre of layer 26 were virtually unaffected. One from the side of layer 8 showed Bar no. 13 just sagging. Two, from layer 14 (centre) and layer 18 (side) had all the bars melted - turned totally to liquid in layer 14. With only six samples it's not really valid to take an average.</p> <p><b>Comments:</b> Bricks are mostly underfired. Specific firing energy is thus quite low. The long firing time indicates not enough air gaps - boiler waste packs 'tighter' than coal. Brick quality and appearance is not good due to poor soil preparation, a worn press machine, and contamination from drying on dirty ground. Bricks are easily broken, revealing no unfired core, but a matrix containing lumps of dry clay and stones - stones too big to make a strong brick. Bricks aren't vitrified but merely quite well 'baked'. Some <i>were</i> 'hard-burned' - turning blue. These corresponded to 'hot-spots' indicated by Thermoscopes. Clamp volume is 39 cubic metres while the volume of bricks is around 27 cubic metres. Void volume is thus 12 cubic metres (about 30%) which includes the volume of coal initially in the clamp.</p> <p><b>Recommendations:</b> Green bricks should be thoroughly dry to save fuel. The firing process needs modifying to produce well-burned bricks. The 'high temperature' soil is difficult to vitrify, needing a temperature of more than <math>1000^{\circ}\text{C}</math>. Experience suggests fuel should be increased by around 20%. More sensibly, this increase could be achieved by ensuring green bricks are dry. The same fuel to brick mass ratio could then be retried. The other problem is air flow. The clamp burned too slowly. Boiler waste could be distributed more evenly throughout, and air gaps between bricks could be increased. Firing time could be reduced to around 7 days.</p> <p><b>Signature, date, organisation &amp; contact address</b> Kelvin Mason, IT-Zimbabwe, PO Box 1744, Harare. Tel: 490270, 496653, 496746/7 Fax: 496041</p>		

technical brief

### MONITORING FORM: Energy consumption of brick firing processes

Name of producer	Location/address	Dates and times of firing Start Finish
Type of clamp/kiln	Type of fuel	Mass of fuel used (kg)
Calorific value (kJ/kg) Gross Net Moisture content (%)	No. of green bricks in kiln	Mass per brick (kg) green dry fired
Brick moisture content (%)	Method of forming	Weather conditions
Calculation of kiln efficiency  Mass of green brick (kg)  Mass of dry brick (kg)  Total moisture content (kg)  Drying energy (kJ)  Total energy (kJ)  Firing energy (kJ)  Mass of fired brick (kg)  Specific firing energy (kJ/kg)		Qualifying information:  (i) Soil vitrification category  (ii) Holdcroft Bar temp. or Buller's Ring no.  <u>And/or</u>  (iii) Avg. firing temp. (°C)  (iv) Firing time (hrs)
Comments		
Signature, date, organisation & contact address		

## References and further reading

- [\*How to Measure the Energy Used to Fire Clay Bricks: A Practical Guide for Brickmakers, Field-workers and Researchers\*](#) Practical Action Technical Brief,
- *Moulding of Clay* GTZ Technical Brief
- [\*Drying of Clay Bricks and Tiles\*](#) Gerhard Merschmeyer, GTZ, Technical Brief 2000
- [\*Firing of Clay Brick and Tiles\*](#) , Gerhard Merschmeyer, GTZ Technical Brief 2000,
- *Brick Clamps* GTZ Technical Brief
- *Building with Interlocking Blocks* GTZ Technical Brief
- *Bull's Trench Brick Kiln* GTZ Technical Brief
- *Hoffmann Kilns* GTZ Technical Brief
- *The Vertical Shaft Brick Kiln* GTZ Technical Brief
- [\*Brick by Brick: Participatory Technology Development in Brickmaking\*](#) by Kelvin Mason, Practical Action Publishing 2001, ISBN 1 853339 529 3

This technical brief was originally written for **basin**, Building Advisory Service and Information Network by Kelvin Mason, April 1998 on behalf of ITDG (Now Practical Action). Special thanks to Ray Austin, Dr Alfredo Barriga (ESPOL) and Mario Jara.

Practical Action  
The Schumacher Centre  
Bourton-on-Dunsmore  
Rugby, Warwickshire, CV23 9QZ  
United Kingdom  
Tel: +44 (0)1926 634400  
Fax: +44 (0)1926 634401  
E-mail: [inforseiv@practicalaction.org.uk](mailto:inforseiv@practicalaction.org.uk)  
Website: <http://practicalaction.org/practicalanswers/>

Soluciones Prácticas (Practical Action Latin America)  
Casilla Postal 18-0620  
Lima 18  
Perú  
T +511 4467324/4447055  
F +511 4466621  
E [info@solucionespracticas.org.pe](mailto:info@solucionespracticas.org.pe)  
W [www.solucionespracticals.org.pe](http://www.solucionespracticals.org.pe)

*This Technical Brief was possible thanks to the collaboration of DFID-UK and The Tony Bullard Trust*

Practical Action is a development charity with a difference. We know the simplest ideas can have the most profound, life-changing effect on poor people across the world. For over 40 years, we have been working closely with some of the world's poorest people - using simple technology to fight poverty and transform their lives for the better. We currently work in 15 countries in Africa, South Asia and Latin America.